

610204
282




FIG. 1

610204





FIG. 2

610204



610204




FIG. 4a

610204




FIG. 4b

610204





FIG. 5a





-50

FIG. 6a

610204




FIG. 6b

610204




FIG. 7a

610204




FIG. 7b

- NOTE 1 CARD EDGE CONNECTOR PIN 1 IS LOCATED ON THE BACK SIDE ON THE LEFT END WHEN VIEWED WITH THE CONNECTOR DOWN.
- NOTE 2 CARD EDGE CONNECTOR PIN NUMBERS ALTERNATE FRONT TO BACK WITH EVEN NUMBERS ON THE SIDE WITH COMPONENTS.
- NOTE 3 EDGE CONNECTOR PIN SPACING IS .100"




FIG. 8a

40




FIG. 8b

APPROVED

D.G.F.

PRINT OF DRAWING AS
ORIGINAL FILED.

Mont Frisbee, Jr.
of 16, NC 65851
G. Keough

610204

90





FIG. 9a



610204




FIG. 9b

